







**COMMON CX<sub>7</sub>**

User Guide 1.0EN





## + Package Contents

			
COWON CX7	Portable Charging Cradle	Quick Guide	
			
S                      M                      L	Normal Type                      Hook Type		
Ear Tips		Silicone Covers	
			USB Type-C Cable


\* Actual package contents may differ from the above images.

\* L-size eartips are attached to the earphones.


## + Before you start \_ Names of Parts and Functions




## + Before you start \_Precautions



\* For charging please remove the protective film from the earphone charging terminal.




\* Do not let the silicone covers cover the earphone charging protrusions.



\* Make sure that the earphone is properly positioned in the fixing groove of the charging cradle and check if the earphone LED is on.


## + Before you start \_ Charging

### Charge the Earphones




- \* Put the earphones in the charging cradle to start charging them automatically.
- \* Charging : The white LED Indicator on your earphones turns on / Charging Complete : The white LED Indicator on your earphones turns off

### Charge the Charging Cradle




- \* Put the USB cable in the Micro USB Port and connect it to the power adapter to start charging.
- \* Charging : Charging cradle LED Indicator blink white (0~25%=1time, 25~50%=2times, 50~75%=3times, 75~100%=4times) / Charging Complete : Stays solid
- \* Please charge the charging cradle periodically. When the cradle battery is discharged, the earphone units may turn-on instead of being charged, causing the earphone to be discharged.

## + Using the Product \_ Auto Power On · Off



When both earphones are removed from the charging cradle, they will automatically turn on.




When inserting the earphones into the charging cradle, the earphone will automatically get turned off.

### Manual Power On · Off

- \* Press the button on the earphone for 4 seconds to turn it on when the power is off. (The blue LED flashes three times)
- \* Press the button on the earphone for 4 seconds to turn it off when the power is on. (The white LED flashes three times)
















## + Using the Product \_ Pairing & Connection



	Remove (Power On)	Turn on Bluetooth	Connect
Description	When both earphones are removed at the same time from the charging cradle, they will automatically turn on. L and R units are connect to each other. Enter pairing mode following an "Pairing Mode" voice.	Turn on Bluetooth on your smartphone or Bluetooth-capable device.	Select 'CX7 Bluetooth' from the list of detected devices to pair and connect automatically.
Voice Prompts	Power On → Connected (In Dual Mode) → Pairing Mode		Pairing Successful

- \* The CX7 supports: Dual mode (Stereo) to use the left and right earphones together and Single mode (Mono) to use them separately.
- \* Remove both the left and right earphones from the charging cradle for use in Dual Mode, or only remove one earphone for use in Single mode.
- \* Putting one earphone in the charging cradle while in Dual mode does not disconnect the other earphone in use.
- \* After the initial pairing, opening the charging cradle lid automatically connects the earphones to the most recently connected device.

## + Using the Product \_ Listening to Music · Calling · Volume Control

	L	R
 x1		
 x2		
 x3		
 2sec		
 4sec		

1) In Dual mode, the microphone of the earphone removed from the cradle first will be enabled. Removing L and R earphones from the cradle at the same time enables the "L" microphone.  
In Single Mode, each earphone will output sound with both microphones enabled for use.

2) Use the Volume Down function with the L earphone and Volume Up function with the R earphone. (In Single mode, only the functions on the earphone currently in use are available.)

3) Press and hold the multifunction button for 3 times to launch the voice recognition feature of your smartphone or tablet. (Android OS : Google Assistant / iOS : Siri / Window OS : Cortana - Except during calls)

4) Use the L earphone to go to the previous track and the R earphone to go to the next track. (In Single mode, only the functions on the earphone currently in use are available.)

- \* By using the CX7 in Single Mode, you can alternate between charging the left and right earphones for extended use. (Audio books, Podcasts, etc.)
- \* Since Single Mode uses only one earphone, you can stay aware of environmental sounds and use the device more safely when walking or bicycling.
- \* Keep the product and a mobile phone within 1 meter when pairing.
- \* If passkey input is required, enter a password or a PIN No.'0000'.
- \* When the CX7 is off, press and hold the multifunction button for 6 seconds to enter pairing mode.



## + Voice Prompts

Status	Voice Prompts
Power On	"Power On"
Power Off	"Power Off"
Bluetooth Connection	"Connected"
Pairing Mode	"Pairing Mode"
Pairing Completed	"Pairing Successful"
Disconnected	"Disconnected"
Incoming call	"Incoming Call" *
Call Ended	"Call Ended"
Low Battery	"Battery Low"

\* For iPhone, user ringtone will be applied.


## + Specification

Bluetooth Version	V5.0
Bluetooth Profiles	HSP / HFP / A2DP / AVRCP
Standby Time	Up to 150 hours
Music-Playing Time	Single Mode : About 7 hours Dual Mode : About 6 hours
Charging Time	CX7 : About 1 hour * Charging Cradle : About 1 hour
Battery	CX7: 3.7V / 50mAh Charging Cradle : 5V / 500mAh
Input	DC 5V / 500mA
Operating Distance	Up to 10m (Free space)
Weight	CX7 : 5g x 2 Charging Cradle : 37g

\* Number of available CX7 charges using charging cradle (500mAh) : 3~4 times (with fully charged charging cradle)

## + Precautions \_ Reset to Dual Mode (When the L and R unit are not connecting to each other)

- \* Refer to page 'Pairing & Connection' when connecting the product to a smart device for the first time.
- \* If the L and R units only connect in single mode during normal dual-mode operation, reset to dual mode by following the instructions below.
- \* If it fails to reset, start again from Step ②.



Delete connected device & Turn off Bluetooth	Power Off	Hold for 10 seconds and release	Release when the LED turns blue	Connection
Delete the [CX7 Bluetooth] device registered on your smartphone or other Bluetooth device and turn off Bluetooth.	Remove the earphones from the cradle and turn off both L and R units.	Press and hold the left and right buttons simultaneously for 10 seconds. Then release them.	Insert the earphones into the charging cradle and check if the earphone LED is on. Then remove the left and right earphones from the charging cradle at the same time. Once reset, the L unit will enter pairing mode, and its LED will flash white and blue.	Turn on Bluetooth on your smartphone or other Bluetooth device and select [CX7 Bluetooth] from the detected devices to complete pairing and automatically connect.

DIGITAL PRIDE.

**©©WON**